# FIRE SAFETY IN THE HOME







#### Did you know ...?

- You're around eight times more likely to die in a fire if you do not have a working smoke alarm in your home.
- Around half of home fires are caused by cooking accidents.
- Two fires a day are started by candles.
- Every six days someone dies from a fire caused by a cigarette.
- About three fires a day are started by heaters.
- Faulty electrics (appliances, wiring and overloaded sockets) cause around 4,000 fires in the home across the country every year.

The easiest way to protect your home and family from fire is with working smoke alarms.

NE WITH

SMOKE

ALARMS


((•)

Get them. Install them. Test them. They could save your life.

#### Choosing your smoke alarms

- Fit at least one smoke alarm on every level of your home.
- Please be aware that some children may not be woken by smoke alarms.
- Smoke alarms are cheap and easy to install.
- They are available from DIY stores, electrical shops and most high street supermarkets.
- Look out for one of these symbols, which shows the alarm is approved and safe.

- Ten-year sealed battery smoke alarms are the best option. They are slightly more expensive, but you save on the cost of replacing batteries.
- There are a variety of different models to choose from. Your local fire and rescue service will be happy to give you advice on which one is best suited for you.



#### How to make sure your smoke alarms work

### Test your smoke alarms at least monthly.

- If any of your smoke alarms have a one year battery, make sure it is changed every year. Only take the battery out when you need to replace it.
- Never disconnect or take the batteries out of your alarm if it goes off by mistake.
- Standard battery operated alarms are the cheapest option, but the batteries need to be replaced every year.
- A lot of people forget to test the batteries, so longer life batteries are better.




- Mains-powered alarms are powered by your home power supply and have a back-up battery in case of a power cut. They need to be installed by a qualified electrician and, like battery alarms, they do require testing.
- Testing smoke alarms tests the smoke sensor as well as the power supply and/or battery.
- You can even have linked alarms installed, so that when one alarm detects a fire they all go off together. This is useful if you live in a large house or over several levels.

Strobe light and vibratingpad alarms are available for those who are deaf or hard of hearing. Contact the Action on Hearing Loss Information Line on **0808 808 0123** or textphone **0808 808 9000**.

#### Fitting your smoke alarms

The ideal position is on the ceiling, in the middle of a room, and in the hallway and landing, so you can hear an alarm throughout your home.

- Don't put alarms in or near kitchens or bathrooms where smoke or steam can set them off by accident.
- If it is difficult for you to fit smoke alarms yourself contact your local fire and rescue service for help. They'll be happy to install them for you.




#### Looking after your smoke alarms

- Make testing your smoke alarms part of your regular household routine.
- Test them by pressing the button until the alarm sounds. If it doesn't sound, you need to replace the battery.
- Vacuum your smoke alarms every six months to remove dust.
- If a smoke alarm starts to beep on a regular basis, you need to replace the battery immediately.
- If it is a ten year alarm, you will need to replace the whole alarm every ten years.

### Other equipment you could consider

- Fire blankets are used to put out a fire or wrap a person whose clothes are on fire. They are best kept in the kitchen.
- Fire extinguishers can be useful if the fire is very small or blocking your exit.
  If you choose to use an extinguisher, always read the instructions before use and don't put yourself in danger.
- Heat alarms can detect fires in kitchens where smoke alarms should not be placed.



# IN THE KITCHEN **ELECTRICS** CIGARETTES CANDLES

This section will tell you how you can avoid fires in your home, including how to cook safely and take care with electrics, heaters, candles and cigarettes.

#### In the kitchen

#### Cook safely


Take extra care if you need to leave the kitchen whilst cooking, take pans off the heat or turn them down to avoid risk.

- Avoid cooking when under the influence of alcohol.
- Avoid leaving children in the kitchen alone when cooking on the hob. Keep matches and sauce pan handles out of their reach to keep them safe.
- Make sure saucepan handles don't stick out – so they don't get knocked off the stove.

- Take care if you're wearing loose clothing – they can easily catch fire.
- Keep tea towels and cloths away from the cooker and hob.
- Spark devices are safer than matches or lighters to light gas cookers, because they don't have a naked flame.
- Double check the cooker is off when you've finished cooking.

#### Take care with electrics

- Keep electrics (leads and appliances) away from water.
- Don't put anything metal in the microwave.



- Check toasters are clean and placed away from curtains and kitchen rolls. Most toasters have a slide out crumb catcher to help you keep it clean.
- Keep the oven, hob and grill clean and in good working order. A build up of fat and grease can ignite a fire.

#### Deep fat frying

- Take care when cooking with hot oil it sets alight easily.
- Make sure food is dry before putting it in hot oil so it doesn't splash.
- If the oil starts to smoke it's too hot. Turn off the heat and leave it to cool.

• Use a thermostat controlled electric deep fat fryer. They can't overheat.

## What to do if a pan catches fire

- Don't take any risks. Turn off the heat if it's safe to do so. Never throw water over it.
- Don't tackle the fire yourself.





#### Electrics

## How to avoid electrical fires

- Always check that you use the right fuse to prevent overheating.
- Make sure an electrical appliance has a British or European safety mark when you buy it.
- Certain appliances, such as washing machines, should have a single plug to themselves, as they are high powered.
- Try and keep to one plug per socket.
- When charging electrical goods, follow the manufacturer's instructions and look for the CE mark that indicates chargers comply with European safety standards.

Keep electrical appliances clean and in good working order to prevent them triggering a fire.




Don't overload

An extension lead or adaptor will have a limit to how many amps it can take, so be careful not to overload them to reduce the risk of a fire.

Appliances use different amounts of power – a television may use a 3amp plug and a vacuum cleaner a 5amp plug for example.

Know the limit!





- Keep your eyes peeled for signs of dangerous or loose wiring such as scorch marks, hot plugs and sockets, fuses that blow or circuit-breakers that trip for no obvious reasons, or flickering lights.
- Check and replace any old cables and leads, especially if they are hidden from view – behind furniture or under carpets and mats.
- Unplugging appliances helps reduce the risk of fire.
- Unplug appliances when you're not using them, they are fully charged, or when you go to bed.

#### Furniture

 Always ensure that your furniture has the fireresistant permanent label.

#### **Portable heaters**

- Try to secure heaters up against a wall to stop them falling over.
- Keep them clear from curtains and furniture and never use them for drying clothes.

#### Using an electric blanket

- Store electric blankets flat, rolled up or loosely folded to prevent damaging the internal wiring.
- Unplug blankets before you get into bed, unless it has a thermostat control for safe all-night use.
- Try not to buy second hand blankets and check regularly for wear and tear.
- Always follow the manufacturer's instructions.



#### Cigarettes

#### Stub cigarettes out properly and dispose of them carefully. Put them out. Right out!

- Never smoke in bed.
- Smoke outdoors and put cigarettes right out – this is safer than smoking indoors.
- Use a proper ashtray never a wastepaper basket.
- Make sure your ashtray can't tip over and is made of a material that won't burn.
- Don't leave a lit cigarette, cigar or pipe lying around. They can easily fall over and start a fire.

- The best way to reduce the risk is to make an attempt to quit, using NHS support if you need it. If you do not want to quit, consider vaping.
- Take extra care if you smoke when you're tired, taking prescription drugs, or if you've been drinking. You might fall asleep and set your bed or sofa on fire.
- Unplug e-cigarettes when fully charged and ensure you are using the correct charger.
- Never smoke illegally manufactured cigarettes.



#### Candles


Make sure candles are secured in a proper holder and away from materials that may catch fire – like curtains.

- Put out candles when you leave the room, and make sure they're out completely at night.
- Children shouldn't be left alone with lit candles.
- Consider using LED or battery-operated candles.
- Keep pets away from lit candle.

- Keep matches and lighters out of children's reach.
- Only buy child resistant lighters and match boxes.

### Matchboxes now carry this warning label...








# PLAN A SAFE ESCAPE

Fitting smoke alarms is the first crucial step to protecting yourself from fire. But what would you do if one went off during the night?

This section will help you make a plan ready for an emergency.

- Plan an escape route and make sure everyone knows how to escape.
- Make sure exits are kept clear.
- The best route is the normal way in and out of your home.
- Think of a second route in case the first one is blocked.
- Take a few minutes to practise your escape plan.
- Review your plan if the layout of your home changes.

Keep door and window keys where everyone can find them.






#### What to do if there is a fire

Don't tackle fires yourself. Leave it to the professionals.

- Keep calm and act quickly, get everyone out as soon as possible.
- Don't waste time investigating what's happened or rescuing valuables.
- If there's smoke, keep low where the air is clearer.
- Before you open a door check if it's warm. If it is, don't open it – fire is on the other side.





#### What to do if your escape is blocked

If you can't get out, get everyone into one room, ideally with a window and a phone.

- Put bedding around the bottom of the door to block out the smoke.
- Call 999 then open the window and shout "HELP FIRE".
- If you're on the ground or first floor, you may be able to escape through a window.
- Use bedding to cushion your fall and lower yourself down carefully. Don't jump.

 If you can't open the window break the glass in the bottom corner. Make jagged edges safe with a towel or blanket.



#### What to do if your clothes catch fire

- Don't run around, you'll make the flames worse.
- Lie down and roll around. It makes it harder for the fire to spread.
- Smother the flames with a heavy material, like a coat or blanket.
- Remember, Stop, Drop and Roll!



#### How to escape from a high level building

- Make sure you, and everyone in your home, know the fire plan for your building and where fire alarms and fire exits are. As with all buildings, you should plan and practise an escape route.
- Avoid using lifts and balconies if there is a fire.
- It is easy to get confused in smoke, so count how many doors you need to go through to reach the stairs.
- Check that your way out is clear and that there is nothing in the corridors or stairways that could catch fire – like boxes or rubbish.

- Make sure doors to stairways are not locked.
- You should still get smoke alarms for your own home, even if there is a warning system in the block.



# MAKE A BEDTIME CHECK

You are more at risk from a fire when asleep. So it's a good idea to check your home before you go to bed.

22

#### **Check list**

| Close inside doors at night to stop<br>a fire from spreading.   |
|---|
| Turn off and unplug electrical<br>appliances unless they are designed<br>to be left on – like your freezer. |
| Check your cooker is turned off.  |
| Don't run appliances such as washing machines, tumble dryers and dishwashers overnight.                     |
| Turn heaters off and put up fireguards.   |
| Put candles and cigarettes out properly.  |
| Make sure exits are kept clear.   |
| Keep door and window keys when<br>everyone can find them.   |
|   |
|   |



# (((• SMOKE A A SA VE **LIVES**

In the event of a fire, get out, stay out and call 999.

For advice specific to you and your home, visit **www.ohfsc.co.uk** and complete your own home fire safety check.

FS069 ©Crown Copyright 2021. Published by the Home Office. November 2021. Printed on paper comprising no less than 75% post-consumer waste. Version 4



Get out, stay out and call 999 ISBN 978-1409845973

